



How to update firmware for the SHS1000 and SHS800 series handheld oscilloscopes

Download the firmware from the Siglent website located at:

<http://www.siglentamerica.com/index.aspx>

Go to the "Product Center" and choose your instrument. Then click on the "Firmware and Software" tab on your specific instrument, locate the most recent software and download the firmware to your PC. Copy the firmware to the root directory of your flash drive. Power up your oscilloscope.

Put the flash drive in the USB slot on the side of the oscilloscope. Press the "User" softkey to enter the Utility menu, then push "Next Page" to page 3/4, and then press "Update Firmware" softkey. With the flash drive in the USB slot press 'F4' softkey to begin installation. Use the arrow keys to scroll down to the appropriate .ADS file to do the update. When the firmware file is highlighted press the "Load" softkey and the oscilloscope will begin to update. Do not interrupt the power to the oscilloscope during this process or the oscilloscope will no longer boot. When the update finishes you will get a message - The firmware has been updated successfully; please cycle power to the DSO. Now turn the DSO off and back on.

Press "User" softkey to enter the Utility menu, then push the "System Status" softkey and verify the correct software version is listed here.